TO:

Distribution

FROM:

D.R. Vinograd

DATE:

April 25, 1973

SUBJECT:

Answerback Coding Requirements for Multics I/O Terminals

This MOSN describes Multics system operation on the Multics series Model 6180.

The following document is intended to describe the conventions/ requirements for the coding of answer back mechanisms for the various I/O terminals that Multics can support.

For terminals of speed 110 baud, 150 baud and 300 baud, commonly referred to as "teletypes", the following answer back coding is used.

> Null, Printer Off, Null, Location Code, Space, Terminal Code, Identification Code, Space, Terminal Code, Identification Code, Printer On, New Line/ Carriage Return/ End of Line

where

Null

is a null character inserted for

timing purposes

Printer Off

is the device dependent character(s)

which turn the printing mechanism off

Location Code is a three (3) letter code indicating

the location of the terminal

Space

is the device dependent code for space;

ascii code 040g

Terminal Code is the code which identifies the terminal type. Codes now defined are:

D - Teletype Model 33

C - Teletype Model 35

B - Teletype Model 37 (without red shift)

E - Terminet 300

T - TI 725/CD1 1300

J - Teletype Mode 38

Identification Code is a three character code indicating a further refinement of the location code

Printer On is the device dependent character(s) which turn the printing mechanism on

New Line/ Carriage Return/ End of Line is the device dependent character which indicates completion of a single line of text.

For terminals of speed 134.5 band commonly referred to as 2741/1050 or selectric like devices, the answer back code is as follows:

0, Password Inhibit, Terminal Code

where

o is the device dependent character representing a zero, ascii code 0608

Password Inhibit is a "letter" if the terminal has the password inhibit feature (printer off) and a digit if not.

Terminal Code is a two character terminal identification code. Codes now defined are:

A - Datel Terminal

5 - Trendata Terminal

0 - 2741 Terminal

B - Novar Terminal