

Published: 10/02/67

Identification

Connect generator procedure
Harlow Frick

Purpose

Connect_generator is a master mode procedure which issues connect signals to all processors in the system. Connect_generator is accessible to those Multics modules which must clear the associative memories of all processors in the system. Each processor clears its associative memory in response to a connect fault as described in BK.3.08.

Discussion

For each processor available to the system, connect_generator performs the following steps:

1. Sets connect_flag for the target processor to non-zero. (See Section BK.4.01 for a description of the connect_flag array.)
2. Issues a connect signal to the target processor.
3. Waits for a positive response from the target processor. When the target processor detects the connect signal, it will respond by clearing its entry in the connect_flag array.

(In the implementation of connect_generator, Steps 1 and 2 are repeated for every processor available to the system before Step 3 is executed.)

Connect_generator is called as follows:

```
call master_mode_ut$connect_generator;
```