MULTICS SYSTEM-PROGRAMMERS MANUAL SECTION BC.2.01A PAGE 1
Published: 09/03/68

<u>Identification</u>

Addenda to BC.2.01 R. M. Graham

The control character NUL(000) has now been defined. It is deleted by all device control modules. Hence, it produces no observable result on any device. There is no carriage movement. In particular, since it is now defined the device does not print $\000$. The NUL character will never appear in a string which has been canonicalized.