MULTICS SYSTEM-PROGRAMMERS * MANUAL

SECTION BY,99.07 PAGE 1

Published: 11/12/68

Identification

rsw_ N. I. Morris

(Note that the following is an Abstract, which should be replaced by a full description at a later time.)

Function of Entry:

Reads switches on Processor. Does not wait for them to be set.

Calling Sequence for Entry:

switches = rsw_;

Declaration of Arguments:

dcl (switches, rsw_ ext entry) bit (36);

Description of Arguments:

Upon return from rsw_, switches will contain the setting of the processor data switches.

N.B.: switches <u>must</u> be in <u>aligned</u> bit string (i.e., not a member of a packed structure).